



Balance™

Knee-tilt



Balance™ - Knee-tilt

1. **Seat Tilt Tension** - While out of the chair, tighten or loosen the resistance with the knob.
2. **Seat Height** - While not seated, lift the wide portion of the lever handle to increase height. Lift the lever while seated to decrease height.
3. **Seat Angle** - Release from lock position by pulling the lever outward. The seat will remain in free-float until you push the lever inward again.
4. **Arm Height** - Adjusts by squeezing the button on the outer support post while moving the pad up or down.
5. **Arm Width** - Get out of the chair to loosen the knob, position arm support to desired width, and then retighten the knob to secure.
6. **Arm Pad Depth** - Adjusts by squeezing the button under the front edge of the arm pad, while sliding the pad forward or rearward for desired depth.