



Cozi™

Forward Pivot Synchro w/ Seat Slider



Cozi™ - Forward Pivot Synchro w/ Seat Slider

1. **Back Height** - Slowly lift the back until you have the appropriate lumbar support. If the back is too high, lift the back all the way up and then lower to the first position.
2. **Seat Tilt Tension** - Rotate it forward to increase tension or turn the control backward to decrease tension.
3. **Seat Height** - Push the lever down and lift your weight to raise the seat to the desired position. To lower the seat, push the lever down while remaining seated.
4. **Seat Slider (Depth)** - Lift the lever to activate seat slider.
5. **Seat & Back Synchronies Angle** - While seated, twist the left side control forward to release seat into rocking mode. Slight rearward pressure against the backrest may be required to regain rocking mode. Lock in any of 5 preset positions by holding that position and rotating the control rearward.
6. **Arm Width** - Loosen the knob under the arm to release the arm and slide the arm to the proper position. Tighten the knob to lock the arm into place.
7. **Arm Height** - Squeeze the lever under the outer edge of the arm pad to adjust the height until your arms are properly supported