



Right Chair®

Forward Pivot Synchro



1. Independent Lumbar

2. Seat Tilt Tension

3. Seat Height

7. Arm Height

6. Arm Width

5. Seat & Back Angle

4. Seat Slider (Depth)

Right Chair® - Forward Pivot Synchro

1. **Independent Lumbar** - To position lumbar height, locate the support inside the backrest frame and move it up or down in a 3" range of motion.
2. **Seat Tilt Tension** - Rotate it forward to increase tension or turn the control backward to decrease tension.
3. **Seat Height** - Push the lever down and lift your weight to raise the seat to the desired position. To lower the seat, push the lever down while remaining seated.
4. **Seat Slider (Depth)** - Lift the lever to activate seat slider.
5. **Seat & Back Synchronies Angle** - While seated, twist the left side control forward to release seat into rocking mode. Slight rearward pressure against the backrest may be required to regain rocking mode. Lock in any of 5 preset positions by holding that position and rotating the control rearward.
6. **Arm Width** - Pull the switch away from the arm to unlock, and then position the arm width. Snap the switch closed to secure your setting.
7. **Arm Height** - Squeeze the button while positioning the arm, and then release to lock into your chosen setting.